


Nexus Setup Instructions

When using a B&K Nexus with SoundCheck it is usually easier to set it up for Unity Gain.

Nexus Home Screen


- Select **Transducer Setup**
- Click Enter (fourth button)



Transducer setup

- Arrow right to **Sensitivity** column
- Arrow down to **Channel 1**
- Enter the value:


0.100V/Pa



Amplifier Setup: Unity Gain

- Click the **Home** button to return to Home Screen
- Select **Amplifier Setup**
- Click **Enter** (fourth button)
- Arrow Right to **Out** column
- Arrow down to **Channel 1**
- Click the **+** button to change value to:

100mV/Pa



Amplifier Setup: +20dB Gain

If you need to add gain to the microphone, increase the level in the **Amplifier** section only.


An increase of +20 dB requires the amplifier output level to increase by a factor of 10:

100 mV/Pa to 1 V/Pa.

Follow the same procedure as shown in [Amplifier Setup: Unity Gain on page 1](#).

- For the last step, click the **+** button to change value to:

1V/Pa



Rev Date 050916

580 Harrison Ave, Suite 3W • Boston, MA 02118 • 617-556-4104 • Fax 617-556-4145 • www.listeninc.com

© Listen, Inc 2000 - 2016. All rights reserved. SoundCheck® is a trademark of Listen, Inc.

® Microsoft, Windows 7 are registered trademarks of Microsoft Corporation.